

# OWNER'S MANUAL

Version 1.1 | 01/09/2021 FAU18PV-MAN

# VACUUM FILTER PRESS



Thank you for purchasing the CDL Vacuum filter press.

This document will assist you in the proper use of this product. It will provide you with all the necessary information you need.

#### **IMPORTANT NOTICE**

Prepare a solution of hot soapy water and add the equivalent of one cup of vinegar (250 ml) or 15 ml (1/2 oz) of acetic acid per gallon (4L) of solution produced. Hand clean each component (stainless steel pipe, fittings, and valves) that may be in contact with maple water or maple syrup. Rinse and dry with a soft, clean cloth. This removes any residual traces of manufacturing oil, polishing paste and / or packing debris.


# TABLE OF CONTENTS

PRODUCT DETAILS	3
PRODUCT FEATURES	4
CAPACITIES AND SIZES	4
INSTALLATION	5
USE	5
SAFETY	6
MAINTENANCE	6
WARRANTY	6
TROUBLESHOOTING	7



# **PRODUCT DETAILS**


SUGARING EQUIPMENT




# **PRODUCT FEATURES**

- Syrup level
- Draw-off valve
- Vacuum manometer with vacuum discharge valve
- Vacuum control valve
- Handle
- Retaining ring
- Filtration grid
- Vacuum relief valve
- Latch clamp

# **CAPACITIES AND SIZES**





	9"	12"	15"	18"
	3.6 Gal US	9 Gal US	14 Gal US	19 Gal US
Α	21-7/32"	28-7/16"	28-7/16"	28-7/16"
В	14"	18"	21-5/32"	24-5/16"
С	15-9/32"	23-7/16"	25-5/8"	29-1/2"



#### **INSTALLATION**

\*Make sure you have thoroughly cleaned the product before using it. Clean filtration grid and tank. Use warm water with dish soap to remove any residue or grease.

- 1. Close draw-off valve and vacuum inlet valve;
- 2. Put filtration grid (side of the welds looking down the tank);
- 3. Put reusable filter (thicker) on grid and a Prefilter (thinner) above;
- **4.** Put stainless steel retaining ring on top and clip the three locking pliers to keep everything in place;
- 5. Use necessary fittings to connect vacuum to valve. A vacuum cleaner(Shop-Vac) with a good suction capacity can also be used to create the vacuum in the tank.

#### **USE**

- 1. Install vacuum filter press underneath the evaporator draw-off valve;
- 2. When beginning to draw syrup, allow the liquid to cover the entire filter surface. Then, gradually begin to open vacuum control valve.
- 3. Close vacuum control valve before the syrup has completely passed through the filters. \*\*Leaving a small amount of syrup on the filters will allow to filter a larger quantity of maple syrup before cleaning filters or replace them.

Note: Depending on quality of syrup and time of the year, it may be necessary to add a certain amount of filtering powder to help filter.



#### **SAFETY**

When using or handling this product, it is important to wear rubber gloves to prevent burns from the hot maple syrup.

#### **MAINTENANCE**

Filters can be reused if cleaning is done after use. Pour hot water over the surface of the filters to dislodge the particles. Once cleaned, leave the filters hanging to dry.

\*\*\*Be careful not to twist the fabric so as not to break the fibers. A crumpled filter will no longer be effective for filtration.

#### **WARRANTY**

Vacuum filter press has 1 year warranty on parts en repair in CDL workshop. This warranty includes breakage and manufacturing defects. The product must be used under normal conditions to be covered by warranty.



# **TROUBLESHOOTING**

Problems	Causes	Solutions
Maple syrup no longer passes through the filters	Filters are clogged  Vacuum is not high enough  Poor quality of maple syrup  Filters did not stay wet during use	Change filters or replace them  Use a more powerful vacuum source  Add filtering powder  Leave a small amount of syrup on the filter while use
There is no vacuum in the tank	There is a loss of thightness in the tanks	Check the seal  Check for leaks and screwed fittings

